



## Auxiliary Entrance IP Camera

### 1. Features

- Up to four auxiliary IP cameras at each entrance
- Automatic camera switching according to lock status
- Video from camera still available
- Allows remote cameras to be connected over the Internet
- Supports standard IP cameras in JPG format

### 2. Applications

- Tracking movement in corridors
- Observing the vestibule space
- Optical state front door inspection



### 3. Description


The program iBell office makes it possible to connect up to four Auxiliary IP Cameras to each configured house entrance.

These cameras can be tied with the door locks so that when the lock is switched on, the video from IP camera that is assigned to this lock is displayed.

This way, for example, when you open the front door, you can look into the entrance hall or check how many people actually entered to the building.

You can also check to see whether the entrance door has closed again.

You can connect any standard IP camera with a JPG video format to the iBell office program.





# Application Note APN062017

## 4. iBell office settings

- The section “Auxiliary Camera IP Address or Domain” contains the URL address of a network IP camera including a video path and additional parameters.
- If the DTMF code is set in the lock setting, the video will be switched from the set camera at the time the door lock is switched on.
- If the DTMF code is not entered, you can manually activate the video from the set IP camera by using the camera button.
- The sections “User Name” and “Password” is useful if the video is protected by a password.

**That is all. Now we can try to show :-)**